

Models BJ8040-01E, BJ8050-08E and BJ8050-59E Frequently Asked Questions

Can I put the stainless steel band from BJ8050-59E on the rubber strap version BJ8050-08E?

The bands are not interchangeable and only the original style band can be used. This is due to the construction of the case and that the end of the band is form fitted for the depth and shape of the case opening. The rubber strap version has a larger and deeper opening when compared to the bracelet version. The case for the titanium/rubber strap model (BJ040-01E) has the same construction as the stainless steel/rubber strap model (BJ8050-08E).



BJ8050-59E Case (bracelet) note: cut out for bracelet



BJ8050-08E Case (strap) note: no cut outs and deeper opening

Each band slides into the case opening. They are not held in with push pins, but rather a retaining ring on the back of the case that is secured with four screws.

How do I remove the band?

To remove the band, unscrew the four screws on the back of the watch and set them aside in a safe place. Remove the retainer ring and set aside in a safe place. Slide the band straight up out of the case. Installation is just the opposite procedure.

How do I size the stainless steel bracelet on BJ8050-59E?

The stainless steel bracelets size via a split pin (Citizen catalog sizing procedure code SP). This pin is commonly used in a large number of our watches. To remove the pin, use a pin pusher and push in the direction of the arrow. Reinstallation is opposite with the larger side of the pin entering the band last. The larger side of the pin is the 'pressure' point that keeps the pin in the band.

What type of finish is used on the titanium case model BJ8040-01E?

This model is finished with our multi-layer glass treatment used in a variety of our titanium models.

Is there a titanium band available for the titanium case model BJ8040-01E?

Not at this time.

What type of crystal is in the 300M Eco Drive watches?

Each model features a 6mm thick mineral glass crystal

How much do the watches weigh?

BJ8040-01E (titanium case/rubber strap) = 3.830 ounces BJ8050-08E (stainless steel case/rubber strap) = 5.775 ounces BJ8050-59E (stainless steel case/stainless steel bracelet) = 8.525 ounces

How big are the cases?

Case measurements for all three are: (non inclusive of crown)9:00 to 3:006:00 to 12:00Case Thickness (back to top)48mm48mm19mm